FOR THE
STANDARDIZED
BARE BASE
LAUNDRY FACILITY
NSN 3510-01-165-6845
Inspect Repair Only As Necessary
(IROAN)

SOW-01-837-1-09950A-2/1

31 JANUARY 2000

1.0 SCOPE.	1
1.1 Background.	1
2.0 APPLICABLE DOCUMENTS.	1
2.1 Military Specifications	1
2.2 Military Standards	1
2.3 Other Government Documents and Publications.	2
2.4 Industry Standards.	2
3.0 REQUIREMENTS	3
3.1 General Tasks.	3
3.2 Detail Tasks.	3
3.2.1 Phase I - Pre-Induction	3
3.2.2 Phase II -IROAN	3
3.2.3 Phase III - Inspection, Testing and Acceptance	5
3.2.4 Phase IV - Packaging, Handling, Storage, and Transportation (PHS&T).	5
3.3 Configuration Management	6
3.3.1 Configuration Status Accounting (CSA)	6
3.3.2 Configuration Control.	6
3.4 Quality Assurance Provisions	6
3.5 Government Furnished Equipment /Government Furnished Materiel	6
3.6 Contractor Furnished Materiel (CFM)	7
3.7 Acceptance	7
3.8 Rejection	7
4.0 REPORTS	7
4.1 Repairable Item Inspection Report.	7
4.2 Monthly Progress Reports.	8
4.3 Pre-Induction Checklist.	8
Pre-Induction Checklist	Appendix A
List of Defective Parts and Assemblies.	Appendix B
List of Repair Parts and Assemblies Required for Repairs	Appendix C

STATEMENT OF WORK FOR THE BARE BASE LAUNDRY FACILITY Inspect Repair Only As Necessary (IROAN)

- 1.0 <u>SCOPE</u>. This Statement of Work (SOW) establishes and sets forth tasks and identifies the work efforts that shall be performed by the Contractor in the IROAN effort of the **Standardized Bare Base Laundry Facility**, hereafter referred to as the **Laundry unit**. This document contains requirements to restore the **Laundry Unit** to Condition Code "A." Condition Code A is defined as "serviceable/issuable without qualification, new, used, repaired or reconditioned materiel which is serviceable and issuable to all customers without limitation or restriction. Includes materiel with more than 6 months shelf-life remaining." National Stock Number (NSN) 3510-01-165-6845 shall be known as the **Laundry Unit**, **Bare Base**.
- 1.1 <u>Background</u>. IROAN is defined as "That maintenance technique which determines the minimum repairs necessary to restore equipment components or assemblies to prescribed maintenance serviceability standards by utilizing all available diagnostic equipment and test procedures in order to minimize disassembly and parts replacement."
- 2.0 <u>APPLICABLE DOCUMENTS</u>. The following documents form a part of this SOW to the extent specified. Unless otherwise specified, the issues of these documents are those listed in the Department of Defense Index of Specifications and Standards (DoDISS) and supplement thereto which is in effect on the date of solicitation. In the event of conflict between the documents referenced herein and the contents of this SOW, the contents of this SOW shall be the superseding requirement.

2.1 MILITARY SPECIFICATIONS

MIL-C-46168 Coating, Aliphatic Polyurethane, Chemical Agent Resistant.

MIL-C-53039 Coating, Aliphatic Polyurethane, Single Component, Chemical Agent

Resistant.

2.2 MILITARY STANDARDS

MIL-STD-129 DoD Standard Practice for Military Marking

MIL-STD-130 Identification Marking of US. Military Property

MIL-STD-461 Requirements for the Control of Electromagnetic Interference

Characteristics of Subsystems and Equipment.

MIL-STD-2073-1C DoD Standard Practice for Military Packaging

MILITARY STANDARDS - (Guidance Only).

MIL-STD-973 Configuration Management

2.3 Other Government Documents and Publications. The following other Government documents, and publications form a part of this SOW to the extent specified herein.

DODD 4160.21-M-1 Defense Materiel Disposition Manual.

DOD 4000.25-1-M MILSTRIP Manual

NAVICPINST 4491.2A Requisitioning of Contractor Furnished Materiel From the

Federal Supply System

SL-3-09950A Field Laundry Unit

TM-09950A-14/1 M/S Laundry Facility, Std Bare Base

TM 09950A-14/1 M/S Laundry Facility, Std Bare Base, Ch00A

TM 09950A-14/1 M/S Laundry Facility, Std Bare Base, Supplement 1

TM 3080-12 Corroison Prevention and Control for Marine Corps Equipment

TM 3080-50 Corrosion Control Procedures Depot Maintenance Activities for

Marine Corps Equipment.

TM 4700-15/1H Ground Equipment Record Procedures.

TM 4750-15/1 Painting and Registration Marking for Marine Corps Combat and

Tactical Equipment.

TM 4750-15/2 Camouflage Paint Patterns.

2.4 Industry Standards.

ANSI/ISO/ASQC Q9002-1994 Quality Systems-Model for Quality Assurance in

Production, Installation, and Servicing

Copies of military specifications and standards are available from the DOD Single Stock Point, Defense Automation Production Service Philadelphia, Building 4D, 700 Robbins Avenue, Philadelphia, PA 19111-5094, Telephone (215) 697-2179 or DSN 442-2179, or http://www.dodssp.daps.mil. Copies of other government documents and publications required by contractors in connection with specific SOW requirements shall be obtained through the contracting officer: Commander, Marine Corps Logistics Bases, (Code 891) Attn: Contracting Officer, 814 Radford Blvd., Albany, Georgia 31704-1128, commercial telephone number (912) 439-6753 or DSN 567-6753. Copies of engineering drawings, if applicable, shall be obtained from Life Cycle Management Center, Attn; Code 825-3, 814 Radford Blvd STE 20320, Albany, Georgia 31704-0320, commercial telephone number (912) 439-6410 or DSN 567-6410.

3.0 REQUIREMENTS

- 3.1 General Tasks. In fulfilling the specified requirements, the Contractor shall:
- a. Provide materials, labor, facilities, missing parts, and repair parts necessary to inspect, diagnose, restore, and test the **Laundry Unit**. Upon completion of IROAN, repaired equipment shall be Condition Code "A".
- b. Provide all tools and test equipment required to test, inspect, repair, and calibrate the **Laundry Unit**.
 - c. Conduct in-process and final on-site testing for witness by an MCLB, Albany, representative.
- d. Be responsible for all structural, electrical and mechanical requirements associated with the restoration of the **Laundry Unit**.
- 3.2 <u>Detail Tasks</u>. The following tasks describe the different phases for IROAN of the **Laundry Unit**.
- 3.2.1 <u>Phase I Pre-induction</u>. A pre-induction inspection analysis shall be performed for each **Laundry Unit** using the Contractor's diagnosis, inspection and testing techniques to determine extent of work and parts required. This inspection shall included all items associated with the **Laundry Unit** as found in TM 09950-A14/1 M/S and SL-3-09950A. These findings shall be annotated on a Pre-Induction Checklist (Appendix A) and shall be provided to the government in accordance with Paragraph 4.0 of this SOW.
- 3.2.2 <u>Phase II IROAN</u>. After pre-induction tests and inspections have been completed, repair of the **Laundry Unit** shall be accomplished in accordance with this SOW. Deficiencies noted on the Pre-Induction Checklist during Phase I shall be repaired/replaced. Components or assemblies shall not be disassembled for replacement of mandatory parts unless that part has failed, or the component assembly wherein the part is located is disassembled for repair.
- a. Pre-Induction Checklist Information recorded on the Pre-Induction Checklist report shall be used as a guide to repair the **Laundry Unit** system in accordance with this SOW.
- b. Technical Instruction (TI) All TI's not previously applied to the **Laundry Unit** shall be applied during the IROAN and shall be annotated on Equipment Record Jacket in accordance with TM 4700-15/1H.
 - c. Corrosion For corrosion prevention and treatment use TM 3080-12 and TM 3080-50.
 - d. Fluid Leaks The following shall be used as a guide in determining degree of fluid loss:
- (1) Class I Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.
- (2) Class II Leakage of fluid great enough to form drops, but not enough to cause drops to fall from the item being checked/inspected.

(3) Class III - Leakage of fluid great enough to form drops that fall from the item being checked/inspected.

NOTE:

A Class I Leak, except in fuel or brake systems, is an acceptable condition at any time and does not require corrective action.

- e. Belts Replace all.
- f. Data Plates All required data plates and decals shall be in place and shall be legible. Each repaired **Laundry Unit** shall have an IROAN data plate affixed to the main unit in close proximity to the existing data plate. The data plate shall meet the requirements of MIL-STD-130 and TM 4750-15/2.
- g. Painting/Coating (Exterior/Interior) If painting/coating is required, refer to TM 4750-15/1 and TM 4750-15/2. The **Laundry Unit** shall be cleaned in accordance with TM 3080-50, Chapter 4, and coated with Aliphatic Polyurethane Coating, in accordance with MIL-C-46168 or MIL-C-53039.
- h. Demilitarization All end items that are identified as non-repairable and require demilitarization codes, shall be reported to the Marine Corps Logistics Bases representatives Code 837-1, who will provide disposition instructions in accordance with DODD 4160.21-M-1.
- i. Electromagnetic Emission All requirements pertaining to control of electromagnetic interference, emission and susceptibility shall be in accordance with MIL-STD-461.

j. Hardware

- (1) Replace broken, unserviceable and/or missing hardware including nuts, bolts, screws, washers, turnlock fasteners, mandatory replacement items, safety, and one-time use items, etc., in accordance with TM 09950A-14/1 M/S and SL-3-09950A. Unserviceable would include any of the above that failed to function properly.
- (2) Ensure proper hardware locking devices are present and operational on all moving mechanical assemblies.
- (3) Hardware normally supplied with commercial parts shall be used unless specifically prohibited.
- k. Hoses All hoses and fittings shall be visually inspected for damage or deterioration. Any hose showing signs of leakage, kinking or separation of outer coating shall be replaced. This inspection shall be performed during the Pre-induction inspection of the **Laundry Unit**.
- 1. Cable Assemblies All cables and cable connections shall be tested and visually inspected for damage or corrosion. Any cable or cable connector showing signs of damage, corrosion

or separation of outer coating shall be repaired/replaced and tested with it's respective component/assembly to assure satisfactory compliance with all operational tests.

m. Filters - Replace all.

3.2.3 Phase III - Inspection, Testing and Acceptance

- a. Inspection, Testing and Acceptance of the **Laundry Unit** shall be conducted in accordance with TM-09950A-14/1 M/S.
- b. The Contractor shall be responsible for conducting required tests and shall ensure all necessary personnel are available to complete the final acceptance. Acceptance tests shall be held at the Contractor facility. MCLB, Albany, Georgia, representatives shall be given a minimum of two weeks notice prior to beginning acceptance testing. The test area shall be cleared of all equipment parts, components, etc., not required for the test.
- c. The Contractor shall be responsible for correcting any deficiencies identified during inspection/testing. MCLB, Albany, Georgia, representatives may require the Contractor to repeat tests or portions thereof, if the original tests fail to demonstrate compliance with this SOW.
- d. Acceptance testing on all **Laundry units** repaired under the provisions of this SOW shall be accomplished in accordance with TM 09950A-14/1M/S. Operational Tests are to be conducted on each **Laundry Unit** upon completion of repairs and prior to the equipment being returned to stock, to insure the unit will perform as required.

3.2.4 Phase IV - Packaging, Handling, Storage, and Transportation (PHS&T).

- a. The contractor shall be responsible for the preservation and packaging of items being repaired under the terms of this statement of work. Items scheduled for long term storage or shipment to overseas destinations shall be in accordance with the Level "A" requirements of MIL-STD-2073-1C, Method 10. Items being scheduled for domestic shipment, immediate use or short-term storage shall be to Level "B" requirements.
 - b. Marking shall be in accordance with MIL-STD-129.
- c. The Marine Corps will provide the contractor with the shipping address(es) for delivery of the repaired equipment. The contractor shall be responsible for arranging for shipment to the pre-designated site(s). The Marine Corps will be responsible for the transportation costs associated with shipping the subject equipment to and from the Contractor."

3.3 Configuration Management

3.3.1 Configuration Status Accounting (CSA).

a. The Contractor shall record and submit data on retrofit accomplished during Phase II. Any approved Modification Instructions (MIs) or Engineering Change Proposals (ECP's) not previously applied shall be applied during Phase II of the IROAN process.

- b. The Contractor shall determine the application status of approved configuration changes by visual inspections to the extent possible. The government will identify the configuration changes to be inspected by furnishing a Configuration Inspection Checklist to the Contractor. The Contractor shall use one checklist per **Laundry Unit** to record their inspection findings along with other required data.
- c. The Contractor shall record serial numbers of the assemblies listed on the Configuration Inspection Checklist. The Contractor shall record the information on the same form that was used to record the application status of configuration changes.
- 3.3.2 <u>Configuration Control</u>. The contractor shall apply configuration control procedures to established configuration items. The contractor shall not implement configuration changes to an item's documented performance or design characteristics without receiving prior written authorization. The baseline configuration has been defined by the written procedures or materials contained in manuals, standards, instructions or engineering drawings. If it is necessary to depart from the authorized configuration baseline, the contractor shall submit a Request for Deviation or Request for Qaiver using MIL-STD-973 (paragraph 5.4.3 or 5.4.4.) as a guide.

3.4 Quality Assurance Provisions

The Contractor shall provide and maintain a Quality System that as a minimum, adheres to the requirements of ANSI/ISO/ASQC Q9002-1994, Quality System Model for Quality Assurance in Production, Installation, and Servicing. The program shall ensure quality throughout all areas to include fabrication, processing, assembly, inspection, test, maintenance, and preparation for delivery and shipping. Unless otherwise specified in the contract, the Contractor shall be responsible for performance of all inspection requirements. The Government reserves the right to perform any of the inspections set forth in the contract where such inspections are deemed necessary to assure products and services conform to the prescribed requirements. The Contractor shall provide an Inspection and Test Plan.

3.5 Government Furnished Equipment (GFE)/Government Furnished Materiel (GFM) GFE is government owned equipment authorized by contract for use by a Commercial/Government

contractor. It is neither consumed during production nor incorporated into any product. GFM is materiel furnished to a contractor that will be consumed during the course of production or incorporated into product being manufactured/remanufactured under a contract/statement of work. In the event the Marine Corps does have GFE/GFM requirements the Management Control Activity (MCA/Code 827-2), Marine Corps Logistics Bases, Albany, Georgia, will coordinate required GFE and will maintain a central control on Marine Corps assets in Contractor's possession. The MCA will forward a GFE Accountability agreement to the Contractor Facility for signature to establish a chain of custody and property responsibilities for Marine Corps assets.

3.6 <u>Contractor Furnished Materiel (CFM)</u> The Marine Corps has adopted the Navy's procedures regarding Contractor Furnished Materiel (NAVICPINST 4491.2A). In the event that Contractor Furnished Materiel is required for repair parts, the contractor shall requisition through the DoD

Supply System. DOD 4000.25-1-M,(MILSTRIP) Chapter 11 authorizes contractors to requisition through the DoD Supply System.

3.7 Acceptance.

The performance of the Contractor and the quality of work delivered, including all equipment furnished and documentation written or compiled, shall be subject to in-process review and inspection during performance. Inspection may be accomplished in-plant or at any work site or location, and Marine Corps representatives shall be permitted to observe the work or to conduct inspection at all reasonable hours. Final inspection and acceptance testing shall be conducted at the Contractor. Final acceptance shall be conducted on 100 percent of items to verify that the units meet all requirements.

3.8 Rejection

Failure to comply with any of the specified requirements listed herein shall be reason for rejection by MCLB, Albany, representative. The Contractor shall, at no additional cost to MCLB, Albany, Georgia, provide the following:

- a. Develop an approach for modification or correction of all deficiencies.
- b. Upon approval of a documented approach, the Contractor shall correct the deficiencies and repeat the verification until an acceptable compliance with acceptance test procedures is demonstrated.

4.0 REPORTS

- 4.1 <u>Repairable Item Inspection Report</u>. The Contractor shall provide a Repairable Item Inspection Report for each **Laundry Unit**. The report shall be identified by United States Marine Corps Serial Number.
- 4.2 <u>Monthly Progress Reports</u>. The Contractor shall provide Monthly Progress Reports summarizing the progress and status of the IROAN Program.
- 4.3 <u>Pre-Induction Checklist</u>. The Contractor shall complete the Pre-Induction Inspection Checklist for each **Laundry Unit** repaired. These documents shall be available during final

acceptance testing. One copy of each document shall be provided to MCLB, Albany, Georgia, Code 837-1, after final acceptance of the **Laundry Unit**.

- a. The inspection checklist shall contain, but not be limited to the following:
 - (1) Laundry Unit serial number. Appendix A
 - (2) Condition Code of Laundry Unit at receipt. Appendix A
 - (3) Results of operational test. Appendix A
 - (4) List of defective parts and assemblies. Appendix B
 - (5) List of repair parts and assemblies required for repairs. Appendix C

(6) Corrosion prevention methods that shall be used. Appendix A

SOW-01-837-1-09950A-2/1 31 JANUARY 2000

PRE-INDUCTION CHECKLIST

Appendix A

Serial number:	Condition Code at receipt:	
Results of operational test:		
List of defective parts and assemble Corrosion prevention methods t	ies required for repairs. Appendix C	

Inspect all components for operating/malfunction/defective parts per TM 09950A-14/1 M/S. Visually check components for leaks, damage, loose parts & hardware. No disassembly of components is allowed unless the component is determined to be defective.

COMPONENTS:	PASS	FAIL	REMARKS:
LAUNDRY FACILITY BARE BASE			
MAIN PLATFORM ASSEMBLY,			
(SEE FIGURE 7-2)			
STORAGE BIN ASSEMBLY,			
(SEE FIGURE 7-3)			
LAUNDRY WASHER ASSEMBLY,			
(SEE FIGURE 7-4)			
LAUNDRY WASHER ASSEMBLY,			
(SEE FIGURE 7-7)			
CLAMP ASSEMBLY,			
(SEE FIGURE 7-13)			
COUPLINGS			
COUPLING HALF, QUICK			
DISCONNECT,			
CAM-LOCKINC ALL ENDS			
PLUG, SQ HD,			
ELBOW, ST BRASS			
BUSHING, BRASS,			
COMPRESSOR UNIT,			
RECIPROCATING,			
(SEE FIGURE 7-14)			
CONTROLLER AND			

COMPONENTS	PASS	FAIL	REMARKS
ELECTRICAL PANEL,			
(SEE FIGURE 7-16)			
WATER HEATER,			
(SEE FIGURE 7-22)			
HEATER FUEL LINE ASSEMBLY,			
(SEE FIGURE 7-23)			
HEATER TIEDOWN ASSEMBLY,			
(SEE FIGURE 7-24)			
LAUNDRY EXTRACTOR,			
(SEE FIGURE 7-25)			
TIE DOWN CLIP ASSEMBLY,			
(SEE FIGURE 7-30)			
WATER PUMP ASSEMBLY,			
(SEE FIGURE 7-31)			
HOSE CONNECT ASSEMBLY,			
(SEE FIGURE 7-32)		-	
PUMP TIEDOWN ASSEMBLY,			
(SEE FIGURE 7-33)			
DRYER ASSEMBLY,			
(SEE FIGURE 7-34)	-		
DRYER FUEL LINE ASSEMBLY,			
(SEE FIGURE 7-23)			
EXHAUST HOSE			
TIEDOWN ASSEMBLY,			
(SEE FIGURE 7-45)			
EXHAUST HOSE			
TIEDOWN ASSEMBLY,			
(SEF, FIGURE 7-46)			
CONDUIT ASSEMBLY,			
(SEE FIGURE 7-47)			
RAIL, SIDE,84 IN LG			
CLOTHES BIN ASSEMBLY,			
(SEF, FIGURE 7-48)			
POWER CABLE ASSEMBLY,			
(SEE FIGURE, 7-49)			
SPACER			
COVER ASSEMBLY RED 1, 2, & 3			
MAIN PLATFORM ASSEMBLY			
PLATFORM, LEFT ASSEMBLY			
PLATFORM, FRAME ASSEMBLY			
DECK, LARGE TOP ASSEMBLY			
DECK, SMALL TOP ASSEMBLY			
DECK, LARGE BOTTOM			
ASSEMBLY			
DECK, SMALL BOTTOM			
ASSEMBLY			
RAIL			
RAIL, SIDE			
SLEEVE			
STRAP, RETAINING,		-	

COMPONENTS	PASS	FAIL	REMARKS
PLATFORM, RIGHT ASSEMBLY			
JOINING PANEL ASSEMBLY			
STORAGE BIN ASSEMBLY			
BIN, LARGE			
PLATFORM			
BIN, SMALL			
COVER ASSEMBLY			
FASTENER, LINK LOCK			
TRAY			
LAUNDRY WASHER			
WASHER ASSEMBLY,			
(SEE FIGURE 7-5)			
PLATE, TANK MOUNTING			
ELBOW, PIPE,			
TEE, PIPE, STL,			
COCK, DRAIN,			
WASHER ASSEMBLY, OPEN END			
COVER, BASE SIDE LEFT			
COVER, BASE FRONT			
COVER, BASE SIDE RIGHT			
SUPPLY INJECTOR ASSEMBLY			
SHELL ASSEMBLY			
SHELL FRONT ASSEMBLY			
SHELL, EXTRUSION			
RING, SHELL			
PLATE, MOUNTING			
MICROSWITCH			
CAM, DOOR			
HANDLE ASSEMBLY,			
DOOR, ASSEMBLY			
BRACKET, HINGE			
CYLINDER ASSEMBLY			
HOUSING, SHAFT SEAL			
GASKET, SHAFT SEAL			
SEAL, PLAIN, STL,			
COVER, SHAFT RETAINER			
SPACER, SHAFT RETAINER			
KEY, MACHINE, STL			
SPIDER,			
GEAR ASSEMBLY,			
SPEED DECREASER			
MOTOR, ALTERNATING			
MOUNT, MOTOR			
BRACKET, MOTOR MOUNT, LEFT			
BRACKET, MOTOR MOUNT, RIGHT			
BELT GUARD ASSEMBLY			
BRACKET, BELT UPPER			
BELT, V, RBR,			
BRACKET, BELT, LOWER LEFT			
PULLEY, GROOVE,			

COMPONENTS	PASS	FAIL	REMARKS
BUSHING, SLEEVE			
V-PULLEY			
BUSHING, SLEEVE			
COVER, SYPHON			
BREAKER			
PIPE, ELBOW			
WATER LEVEL FLOAT,			
CHAMBER ASSEMBLY,	_		
(SEE FIC3URE 7-6)			
SOAP CHUTE			
COVER, SOAP CHUTE			
HINGE, SOAP CHUTE			
ROD, SOAP CHUTE			
PIPE, METALLIC			
HOSE, NONMETALLIC,			
PIPE, WATER INLET			
VALVE, ANGLE,			
WATER LEVEL FLOAT			
CHAMBER ASSEMBLY			
SWITCH, LIQUID LEVEL			
TUBING, GLASS,			
CLAMP, LOOP			
BRACKET, LEVEL CONTROL			
BRACKET, TOP FLOAT			
CHAMBER			
BRACKET, BOTTOM			
FLOAT CHAMBER			
FLOAT ASSEMBLY,			
LIQUID LEVEL			
FLOAT			
ROD,FLOAT,			
SPFED NUT			
LAUNDRY WASHER ASSEMBLY			
FRAME ASSEMBLY			
DOOR ASSEMBLY,			
(SEE FIGURE 7-8)			
DOOR LOCK ASSEMBLY, (SEE FIGURE 7-9)			
DRAW BAND, WASHER			
EXTRACTOR			
GASKET, RBR CHLOROPRENE			
DRUM FRONT			
CYLINDER ASSEMBLY			
SPIDER AND SHAFT ASSEMBLY			
ROD, THREADED END			
RING, GASKET CLAMP			
GASKET, SOCK			
MOTOR			
PLATE, MOTOR MOUNTING			
ROD, MOTOR ADJUSTING			

COMPONENTS	PASS	FAIL	REMARKS
BELT			
PULLFY, GROOVE,			
BUSHING, SHEAVE			
DRUM ASSEMBLY			
WATER INLET ASSEMBLY,			
(SEE FIGURE 7-10)			
SHEAVE			
BUSHING, SHEAVE			
GEAR ASSEMBLY,			
PLATE, MOUNTING			
SEAL AND CARRIAGE ASSEMBLY,			
SEAL, PLAIN			
DISPENSER ASSEMBLY,			
(SEE FIGURE 7-11)			
GAUGE, TEMPERATURE			
BOTTLE, SUPPLY			
VALVE ASSEMBLY, DRAIN,			
(SEE FIGURE 7-12)			
PLUG, PIPE			
HOSE, DRAIN			
DOOR ASSEMBLY			
DOOR HINGE AND		-	
HANDLE			
BASE, DOOR HINGE			
BUSHING, FLANGE,		-	
PIN, DOOR HINGE			
BEARING, WASHER,			
BAR, DOOR			
FASTENER, PAWL			
BOLT, PIVOT			
BUSHING, SLEEVE			
RING, RETAINING			
WINDOW, OBSERVATION, GLASS,			
GASKET, DOOR GLASS			
FRAME, DOOR			
DRAW BAND, DOOR			
GASKET, DRAW BAND			
GASKET, DOOR			
DOOR LOCK ASSEMBLY			
DOOR LOCK COVER AND SWITCH			
COVER, DOOR LOCK			
SWITCH, PUSH			
BOOT, DUST AND MOISTURE SEAL			
BRACKET, MOUNTING			
BUSHING, ELECTRICAL			
CONDUCTOR,			
SOLENOID,			
SWITCH,			
PLATE, DOOR LOCK			
SPRING, DOOR LOCK			

COMPONENTS	PASS	FAIL	REMARKS
BAR, DOOR LOCK			
SPRING, DOOR LATCH			
WATER INLET ASSEMBLY			
LEVER, MANUAL CONTROL			
CLEVIS, ROD END,			
CYLINDER ASSEMBLY,			
ROD, ADJUSTINC STUD			
BRACKET, MOUNTING			
COUPLER, FEMALE			
COUPLING HALF,QUICK			
DISCONNECT,			
ELBOW, PIPE,			
NIPPLE, PIPE,			
PIPE, METALLIC,			
ELBOW, PIPE TO HOSE,			
ELBOW, PIPE,			
BUSHING, PIPE			
TEE, PIPE			
VALVE, BALL,			
NIPPLE, PIPE,			
DISPENSER ASSEMBLY			
DISPENSER			
COVER			
HOSE, SUPPLY1			
SUPPLY HOSE, AIR			
HOSE, SUPPLY 2			
HOSE, SUPPLY 3			
HOSE, SUPPLY 4			
FITTING, HOSE			
COUPLING, PIPE,			
HOSE, SUPPLY INLET			
ADAPTER, STRAIGHT			
VALVE, SOLENOID,			
MANIFOLD, SUPPLY			
BRACKET, MANIFOLD			
MOUNTING			
DRAIN VALVE ASSEMBLY			
PLATE,TOP			
BELLOWS, RUBBER,			
ADAPTER, STRAIGHT,			
PLATE, MOUNTING			
BRACKET			
HOSE, NONMETALLIC,			
PINCH TUBE			
CLAMP ASSEMBLY			
ANGLE			
ROD,THREADED, SHORT			
RING, HANGER			
AIR COMPRESSOR ASSEMBLY			
GRILLE, METAL			

COMPONENTS	PASS	FAIL	REMARKS
HANDLE, DOOR, L STYLE			
KIT, SWITCH, (SEE FIGURE 7-15)			
HOUSING, AIR COMPRESSOR			
CYLINDER, HEAD ASSEMBLY,			
RIGHT HAND			
CYLINDER HEAD ASSEMBLY,			
LEFT HAND			
MOTOR, ALTERNATING			
CABLE ASSEMBLY,			
PRESSURE SWITCH ASSEMBLY			
SWITCH, PRESSURE			
PLUG, BUTTON			
WIRE ASSEMBLY, BLK			
WIRE ASSEMBLY, WHT			
CONTROLLER AND			
ELECTRICAL PANEL SUPPORT			
FRAME ASSEMBLY			
FACE PLATE, LAUNDRY,			
COVER, CONTROLLER			
CONTROLLER ASSEMBLY			-
HEAD ASSEMBLY,			
CONTROL BOX, (SEE FIGURE 7-17)			
CONTROL BOX ASSEMBLY,			
(SEE FIGURE 7-18)			
CONTROL CHASIS			
ASSEMBLY, LAUNDRY,			
(SEE FIGURE 7-19)			
HOSE, LOW PRESSURE			-
ADAPTER, STRAIGHT			-
SLEEVE			
FIRE EXTINGUISHER		-	
PLATE, MOUNTING			
STAND, CONTROLLER SUPPORT			
LOAD CENTER			
ENCLOSURE			
BRACKET, INTERIOR MOUNT			
KIT, INTERIOR TRIM			
CAP, END SEAL			
MAIN BREAKER, 30 AMP	-		
CIRCUIT BREAKER, 20 AMP			
BOX, 3 GANG			
GASKET, SYNTH-RBR,			
CONNECTOR, RECEPTACLE			
OUTLET			
COVER, CONDUIT			
COVER, LIFT			
SWITCH, MOTOR STARTING			
HEAD ASSEMBLY			
WINDOW, OBSERVATION,			
LATCH, SPECIAL			

COMPONENTS	PASS	FAIL	REMARKS
LAMP, 28V			
SOCKET, LAMP			
NAME PLATE			
WARNING			
NAME PLATE,			
TUBING,			
TYRAP,			
BRACKET, RECEPTACLE			
RECEPTACLE			
ANGLE, CENTER			
DOOR ASSEMBLY, PLASTIC			
WET PART, LAUNDRY			
PARTITION, SWITCH			
SKIRT, TIMING, LAUNDRY			
REAR ASSEMBLY			
BACK			
POWER SUPPLY			
VALVE, SOLENOID,			
STRAINER, SEDIMENT,			
NIPPLE, PIPE,			
ANGLE			
PLUG, PIPE			
BLOCK, MANIFOLD,			
CONTROL CHASIS ASSEMBLY			
CONTROL PANEL ASSEMBLY,			
(SEE FIGURE 7-20)			
FUSE, CARTRIDGE,			
FUSEHOLDER,			
VALVE, SOLENOID,			
VALVE, AIR CONTROL, 3 WAY			
RELAY, 3PDT, IO AMP			
SWITCH, PRESSURE			
RELAY,			
TIMING MOVEMENT,			
MECHANICAL,			
(SEE FIGURE 7-21)			
CONTROL PANEL ASSEMBLY			
PANEL, CONTROL			
TIMER, SEQUENTIAL			
SWITCH, TOGGLE,			
COVER, SWITCH			
REVERSING TIMER ASSEMBLY			
SHAFT, SHOULDERED,			
SWITCH, SENSITIVE,			
ADAPTER, SWITCH CAM, CONTROL			
•			
SETSCREW, BRACKET, TIMER			
LAUNDRY EXTRACTOR			
ASSEMBLY			
ASSEMIDL I			

COMPONENTS	PASS	FAIL	REMARKS
EXTRACTOR, BOCK MOISTRITE			
AND SPEEDRY			
MOTOR ASSEMBLY,			
(SEE FIGURE 7-26)			
MOTOR ASSEMBLY,			
(SEE FIGURE 7-27)			
SHEAVE, PULLEY			
V-BELT			
LID			
FRAME, LID HINCE			
BASKET BALL			
LID GASKET			
CURB ASSEMBLY			
WASHER, LEAD			
RUBBER WASHER			
HOSE,			
BASKET ASSEMBLY			
POST,CENTER			
SEAL,			
CENTER UNIT ASSEMBLY,			
(SEE FIGURE 7-28)			
HUB, BRAKE			
BACK PANEL ASSEMBLY,			
(SEE FIGURE 7,29)			
BASE ASSEMBLY			
TRUNNION FRAME, ASSEMBLY			
COUPLING HALF,			
MOTOR ASSEMBLY #1			
MOTOR, 3 HP			
SWITCH,			
MOUNT, SWITCH			
COUPLING			
HUB, BODY,			
PLATE, MOTOR MOUNT			
MOTOR ASSEMBLY #2			
MOTOR			
HUB, PULLEY			
PLATE, MOTOR MOUNT			
CENTER UNIT ASSEMBLY			
PIN, STUD			
ARM,BRAKE			
ARM, OPERATING			
BRACKET			
SPRING, HELICAL, EXTENSION			
BRAKE SHOE,			
COVER, TOP END			
SHIELD, SOLENOID			
ROD, SOLENOID			
SOLENOID, BRAKE			
HUB			

COMPONENTS	PASS	FAIL	REMARKS
BALL,BASKET			
INSERT, NYLON			
PACKING,			
CAP, BUMPER			
BUMPER RUBBERS			
CAP, TRUNNION			
RUBBER, TRUNNION			
HUB, PULLEY			
SHEAVES, PULLEY			
BACK PANEL ASSEMBLY			
BUTTON, START			
SWITCH, PUSH-PULL,			
BUTTON, RED			
LIGHT, INDICATOR			
MICROSWITCH			
SOLENOID,			
RELAY,ELECTRO MAGNETIC			
TIMER,			
FUSE HOLDER			
FUSE, CARTRIDGE,	-		
TERMINAL BOARD			
COVER			
PLATE, BOTTOM	-		
BACK AND SIDES, CONTROL			
PANEL			
PLATE, MOUNT			
PLATE,TOP			
TIE DOWN CLIP ASSEMBLY			
BAR, TIE DOWN CLIP			
LEG, TIE DOWN CLIP			
PLATFORMS			
WATER PUMP ASSEMBLY			
WATER PUMP ASSEMBLY			
FRAME, AL-ALY			
SWITCH BOX ASSEMBLY			
COVERS			
COVER,BOX,FRONT			
PUMP UNIT			
BRACKET			
MOTOR, ALTERNATING			
CAP,			
COUPLING HALF,			
NIPPLE, PIPE			
HOSE CONNECTION ASSEMBLY			
SUCTION STRAINER ASSEMBLY			
COUPLING, QUICK DISCONNECT			
SUCTION HOSE ASSEMBLY			
COUPLING, HALF			
HEATER INTAKE HOSE ASSEMBLY			
WASHER, INTAKE HOSE			

COMPONENTS	PASS	FAIL	REMARKS
ASSEMBLY			
HOSES, WATER,			
CLOTHES BIN DISCHARGE HOSE			
EXTRACTOR DISCHARGE HOSE			
ASSEMBLY			
PUMP TIE DOWN ASSEMBLY			
CATCH, FIXED ASSEMBLY			
CATCH, ADJUSTABLE			
PLATFORM ASSEMBLY			
DRYER ASSEMBLY			
BLOWER ASSEMBLY,			
(SEE FIGURE 7-35)			
HOSE ASSEMBLIES			
BURNER TUMBLER ASSEMBLY,			
(SEE FIGURE 7-36)			
SWITCHES, SENSITIVE			
COVER			
LIGHT, INDICATOR,			
ALARM,BUZZER			
BUZZER,			
DOOR ASSEMBLY			
CHAIN, WELDLESS			
TIMER, SEQUENTIAL			
PLATE, INDENT			
LABEL, CAUTION			
LABEL, WARNING			
ARROW			
HANDLE, DOOR			
RING ASSEMBLY			
FRONT SHELL ASSEMBLY,			
(SEE FIGURE 7-39)			
HEATER TUMBLER ASSEMBLY,			
(SEE FIGURE 7-40)			
HOSE, AIR DUCT,			
HOSE, FLEX			
EXHAUST HOSE ADAPTER			
ASSEMBLY			
DUCT, HOSE,			
REDUCER, PIPE,			
ELBOW, AIR CONDITIONING			
HEATING DDL AGGENTOL V			
PIN ASSEMBLY			
PIN GAFETY			
CHAIN, SAFETY			
HOOK, CHAIN,			
THERMOMETER			
DISCHARGE SPOUT ASSEMBLY			
COUPLING, HALF			
CONTROL, TEMPERATURE, DIAL			
AND KNOB			

COMPONENTS	PASS	FAIL	REMARKS
CONNECTOR, ELBOW,			
BOX CONNECTOR,			
FAN ASSEMBLY, (SEE FIGURE 7-			
41)			
COVER			
CONTROL PANEL ASSEMBLY,			
(SEE FIGURE 7-42)			
TUMBLER SPEED REDUCER			
ASSEMBLY,			
(SEE FIGURE 7-43)			
ROD, THREADED			
CUP, GREASE,			
CUP OIL,			
PLATES, RETAINING,			
GUARD			
CHAIN, STL, 65 LINKS			
WIRE, SAFETY			
TUMBLER ASSEMBLY,			
(SEE, FIGURE 7-44)			
SHELL ASSEMBLY			
TUMBLER BASE ASSEMBLY			
PANEL, SIDE			
INSULATOR,PLATE,			
STRIP			
BLOWER ASSEMBLY			
GUAGE, PRESSURE			
COCK, DRAIN			
TEE			
NIPPLE			
PUMP, FUEL			
SHUTTER ASSEMBLY,			
HOUSING			
HOUSING, BLOWER			
WHEEL, BLOWER			
MOUNT, BLOWER			
KEY			
MOTOR, ALTERNATING			
BURNER TUMBLER ASSEMBLY			
CAP FITTING			
GASKET, PEEP SIGHT,			
GLASS, PEEP HOLE			
NIPPLE			
COVER			
CABLE AND TERMINAL			
ASSEMBLY,			
(SEE FIGURE 7-37)			
ELECTRODE ASSEMBLY,			
(SEE FIGURE 7-38)			
BRACKET, TRANSFORMER			
TRANSFORMER			

COMPONENTS	PASS	FAIL	REMARKS
BOX, JUNCTION			
COVER			
BOX CONNECTORS,			
CONNECTOR, STRAIGHT			
AIR PLENUM			
CABLE AND TERMINAL			
ASSEMBLY			
CABLE			
TERMINAL, LUG,			
ELECTRODE ASSEMBLY			
ELECTRODE			
NOZZLE ASSEMBLY			
NOZZLE			
PIPE			
BASE, BURNER FRONT SHELL ASSEMBLY			
DOOR			
HINGE ASSEMBLY			
HINGE			
PIN, SPRING			
FRONT, SHELL			
HEATER TUMBLER ASSEMBLY			
SCREEN ASSEMBLY,			
PANEL, COVER			
HOOD ASSEMBLY			
HOOD			
PLATE			
COVER, FRONT			
COVER, REAR			
BURNER MOUNTING ASSEMBLY			
RETURN BOX NO 5 ASSEMBLY			
COVER, ASSEMBLY			
RETURN BOX NO 3 ASSEMBLY			
RETURN BOX NO 1 ASSEMBLY			
RETURN BOX NO 4 ASSEMBLY			
RETURN BOX NO 2 ASSEMBLY			
MOUNTING PLATE ASSEMBLY			
FAN ASSEMBLY FAN			
MOTOR, ALTERNATING,			
ARROW			
COVER, WELDMENT			
CONTROL PANEL ASSEMBLY			
STARTER, MANUAL			
PANEL ASSEMBLY			
CONTROL, FLAME			
PROGRAM TIME CARD,			
TERMINAL BOX, 12 SGL			
RELAY			
BASE, RELAY,			

COMPONENTS	PASS	FAIL	REMARKS
SHIELD ASSEMBLY			
MOTOR, STARTER			
HEATER ELEMENT,			
TUMBLER SPEED REDUCER			
ASSEMBLY			
MOTOR, ALTERNATING			
MOUNTING BRACKET ASSEMBLY			
BASE ASSEMBLY			
TUMBLER ASSEMBLY			
TIE ROD			
RIB, TUMBLER,			
SPIDER ASSEMBLY			
TUMBLER, CLOTHES DRYER			
EXHAUST TIE DOWN			
ASSEMBLY#1			
LEG		-	
STRAP, WEBBING,			
LOOP			
THREAD			
EXHAUST TIE DOWN			
ASSEMBLY#2			
LEG			
STRAP			
LOOP			
THREAD		-	
CONDUIT ASSEMBLY			
GROUND ROD, SECTION			
CONNECTOR, GROUND ROD			
WIRE, #8 STRANDED			
CONDUIT OUTLET			
COVER			
COVER, BLANK			
BODY, CONNECTOR			
COVER,CONNECTER			
PLUG, NYLON			
PLUG, COVER			
CONNECTOR			
BOX, TWO GANG			
BOX CONNECTOR,			
CLOTHES BIN ASSEMBLY			
HANDLE, SHORT	-		
HANDLE, LONG			
SIDE			
BASE			
COUPLING			
STAND, CLOTHES BIN			
CASTOR			
PLATFORM POWER CARLE ASSEMBLY			
POWER CABLE ASSEMBLY BODY			
-			

SOW-01-837-1-09950A-2/1 31 JANUARY 2000	PRE	-INDUC	TION CHECKLIST	Appendix A
COMPONENTS	PASS	FAIL	REMARKS	
SHIELD, ELECTRICAL CABLE				

LAUNDRY FACILITY BARE BASE	
MAIN PLATFORM ASSEMBLY,	
(SEE FIGURE 7 2)	
STORAGE BIN ASSEMBLY,	
(SEE FIGURE 7 3)	
LAUNDRY WASHER ASSEMBLY,	
(SEE FIGURE 7-4)	
LAUNDRY WASHER ASSEMBLY,	
(SEE FIGURE 7 7)	
CLAMP ASSEMBLY,	
(SEE FIGURE 7-13)	
COUPLING	
COUPLING HALF,	
QUICK DISCONNECT,	
CAM-LOCKINC ALL ENDS	
PLUG, SQ HD,	
ELBOW, ST BRASS	
BUSHING, BRASS,	
COMPRESSOR UNIT,	
RECIPROCATING,	
(SEE FIGURE 7-14)	
CONTROLLER AND	
ELECTRICAL PANEL,	
(SEE FIGURE 7-16)	
WATER HEATER,	
(SEE FIGURE 7-22)	
HEATER FUEL LINE ASSEMBLY,	
(SEE FIGURE 7-23)	
HEATER TIEDOWN ASSEMBLY,	
(SEE FIGURE 7-24)	
LAUNDRY EXTRACTOR,	
(SEE FIGURE 7-25)	
TIE DOWN CLIP ASSEMBLY,	
(SEE FIGURE 7-30)	
WATER PUMP ASSEMBLY,	
(SEE FIGURE 7-3 1)	
HOSE CONNECT ASSEMBLY,	
(SEE FIGURE 7 32)	
PUMP TIEDOWN ASSEMBLY,	
(SEE FIGURE 7 33)	
DRYER ASSEMBLY,	
(SEE FIGURE 7-34)	
DRYER FUEL LINE ASSEMBLY,	
(SEE FIGURE 7-23)	
EXHAUST HOSE	
TIEDOWN ASSEMBLY,	
(SEE FIGURE 7-45)	
EXHAUST HOSE	
TIEDOWN ASSEMBLY,	
(SEE, FIGURE 7-46)	

COMPONENTS:	REMARKS:

CONTRACTOR AND M	
CONDUIT ASSEMBLY,	
(SEE FIGURE 7-47)	
RAIL, SIDE, 84 IN LG	
CLOTHES BIN ASSEMBLY,	
(SEE, FIGURE 7-49)	
POWER CABLEASSEMBLY,	
(SEE FIGURE, 7 49)	
SPACER	
COVER ASSEMBLY RED 1, 2, & 3	
MAIN PLATFORM ASSEMBLY	
PLATFORM, LEFT ASSEMBLY	
PLATFORM, FRAME ASSEMBLY	
DECK, LARGE TOP ASSEMBLY	
DECK, SMALL TOP ASSEMBLY	
DECK, LARGE BOTTOM ASSEMBLY	
DECK, SMALL BOTTOM ASSEMBLY RAIL	
RAIL, SIDE	
SLEEVE	
STRAP, RETAINING,	
PLATFORM, RIGHT ASSEMBLY	
JOINING PANEL ASSEMBLY	
STORAGE BIN ASSEMBLY	
BIN, LARGE	
PLATFORM	
BIN, SMALL	
COVER ASSEMBLY	
FASTENER, LINK LOCK	
TRAY	
LAUNDRY WASHER	
WASHER ASSEMBLY,	
(SEE FIGURE 7-5)	
PLATE, TANK MOUNTING	
ELBOW, PIPE,	
TEE, PIPE, STL,	
COCK, DRAIN,	
WASHER ASSEMBLY, OPEN END	
COVER, BASE SIDE LEFT	
COVER, BASE FRONT	
COVER, BASE SIDE RIGHT	
SUPPLY INJECTOR ASSEMBLY	
SHELL ASSEMBLY	
SHELL FRONT ASSEMBLY	
SHELL, EXTRUSION	
RING, SHELL	
PLATE, MOUNTING	
MICROSWITCH	
CAM, CONTROL	
HANDLE ASSEMBLY	
DOOR, ASSEMBLY	

COMPONENTS. REMARKS	COMPONENTS:	REMARKS
---------------------	-------------	---------

DD ACKET IDICE	
BRACKET, HINGE	
CYLINDER ASSEMBLY	
HOUSING, SHAFT SEAL	
GASKET, SHAFTSEAL	
SEAL, PLAIN, STL,	
COVER, SHAFT RETAINER	
SPACER, SHAFT RETAINER	
KEY, MACHINE, STL	
SPIDER,	
GEAR ASSEMBLY, SPEED DECREASER	
MOTOR, ALTERNATING	
MOUNT, MOTOR MOUNT LEET	
BRACKET, MOTOR MOUNT, LEFT BRACKET, MOTOR MOUNT, RIGHT	
BELT GUARD ASSEMBLY	<u> </u>
BRACKET, BELT UPPER	
BELT, V, RBR,	
BRACKET, BELT, LOWER LEFT	
PULLEY, GROOVE,	
BUSHING, SLEEVE	
V-PULLEY	
BUSHING, SLEEVE	
COVER, SYPHON	
BREAKER	
PIPE, ELBOW	
WATER LEVEL FLOAT,	
CHAMBER ASSEMBLY,	
(SEE FIC3URE 7-6)	
SOAP CHUTE	
COVER, SOAP CHUTE	
HINGE, SOAP CHUTE	
ROD, SOAP CHUTE	
PIPE, METALLIC	
HOSE, NONMETALLIC,	
PIPE, WATER INLET	
VALVE, ANGLE,	
WATER LEVEL FLOAT	
CHAMBER ASSEMBLY	
SWITCH, LIQUID LEVEL	
TUBING, GLASS,	
CLAMP, LOOP	
BRACKET, LEVEL CONTROL	
BRACKET, TOP FLOAT	
CHAMBER	
BRACKET, BOTTOM	
FLOAT CHAMBER	
FLOAT ASSEMBLY,	
LIQUID LEVEL	
FLOAT	

ROD, FLOAT,	
SPEED NUT	
LAUNDRY WASHER ASSEMBLY	
FRAME ASSEMBLY	
DOOR ASSEMBLY, (SEE FIGURE 7-	
8)	
DOOR LOCK ASSEMBLY,	
(SEE FIGURE 7-9)	
DRAW BAND, WASHER	
EXTRACTOR	
GASKET, RBR CHLOROPRENE	
DRUM FRONT	
CYLINDER ASSEMBLY	
SPIDER AND SHAFT ASSEMBLY	
ROD, THREADED END	
RING, GASKET CLAMP	
GASKET, SOCK	
MOTOR	
PLATE, MOTOR MOUNTING	
ROD, MOTOR ADJUSTING	
BELT	
PULLFY, GROOVE,	
BUSHING, SHEAVE	
DRUM ASSEMBLY	
WATER INLET ASSEMBLY,	
(SEE FIGURE 7-10)	
SHEAVE	
BUSHING, SHEAVE	
GEAR ASSEMBLY,	
PLATE, MOUNTING	
SEAL AND CARRIAGE ASSEMBLY,	
SEAL, PLAIN	
DISPENSER ASSEMBLY,	
(SEE FIGURE 7-11)	
GAUGE, TEMPERATURE	
BOTTLE, SUPPLY	
VALVE ASSEMBLY,DRAIN,	
(SEE FIGURE 7-12)	
PLUG, PIPE	
HOSE, DRAIN	
DOOR ASSEMBLY	
DOOR HINGE AND	
HANDLE	
BASE, DOOR HINGE	
BUSHING, FLANGE,	
PIN, DOOR HINGE	
BEARING, WASHER,	
BAR, DOOR	
FASTENER, PAWL	
BOLT, PIVOT	

BUSHING, SLEEVE	
RING, RETAINING	
WINDOW, OBSERVATION, GLASS,	
GASKET, DOOR GLASS	
FRAME, DOOR	
DRAW BAND, DOOR	
GASKET, DRAW BAND	
GASKET, DOOR	
DOOR LOCK ASSEMBLY	
DOOR LOCK COVER AND SWITCH	
COVER, DOOR LOCK	
SWITCH, PUSH	
BOOT, DUST AND MOISTURE SEAL	
BRACKET, MOUNTING	
BUSHING, ELECTRICAL	
CONDUCTOR,	
SOLENOID,	
SWITCH,	
PLATE, DOOR LOCK	
SPRING, DOOR LOCK	
BAR, DOOR LOCK	
SPRING, DOOR LATCH	
WATER INLET ASSEMBLY	
LEVER, MANUAL CONTROL	
CLEVIS, ROD END,	
CYLINDER ASSEMBLY,	
ROD, ADJUSTINC STUD	
BRACKET, MOUNTING	
COUPLER, FEMALE	
COUPLING HALF,QUICK	
DISCONNECT,	
ELBOW, PIPE,	
NIPPLE, PIPE,	
PIPE, METALLIC,	
ELBOW, PIPE TO HOSE,	
ELBOW, PIPE,	
BUSHING, PIPE	
TEE, PIPE	
VALVE, BALL,	
NIPPLE, PIPE,	
DISPENSER ASSEMBLY	
DISPENSER	
COVER	
HOSE, SUPPLY1	
SUPPLY HOSE, AIR	
HOSE, SUPPLY 2	
HOSE, SUPPLY 3	
HOSE, SUPPLY 4	
FITTING, HOSE	
COUPLING, PIPE,	

COMPONENTS:	REMARKS:
HOSE, SUPPLY INLET	
ADAPTER, STRAIGHT	
VALVE, SOLENOID,	
MANIFOLD, SUPPLY	
BRACKET, MANIFOLD	
MOUNTING	
DRAIN VALVE ASSEMBLY	
PLATE, TOP	
BELLOWS, RUBBER,	
ADAPTER, STRAIGHT,	
PLATE, MOUNTING	
BRACKET	
HOSE, NONMETALLIC,	
PINCH TUBE	
CLAMP ASSEMBLY	
ANGLE	
ROD, THREADED, SHORT	
RING, HANGER	
AIR COMPRESSOR ASSEMBLY	
GRILLE, METAL	
HANDLE, DOOR, L STYLE	
KIT, SWITCH, (SEE FIGURE 7-15)	
HOUSING, AIR COMPRESSOR	
CYLINDER, HEAD ASSEMBLY,	
RIGHT HAND	
CYLINDER HEAD ASSEMBLY,	
LEFT HAND	
MOTOR, ALTERNATING	
CABLE ASSEMBLY,	
PRESSURE SWITCH ASSEMBLY	
SWITCH, PRESSURE	
PLUG, BUTTON	
WIRE ASSEMBLY, BLK	
WIRE ASSEMBLY, WHT	
CONTROLLER AND ELECTRICAL	
PANELSUPPORT FRAME	
ASSEMBLY	
FACE PLATE, LAUNDRY,	
COVER, CONTROLLER	
CONTROLLER ASSEMBLY	
HEAD ASSEMBLY,	
CONTROL BOX, (SEE FIGURE 7-17)	
CONTROL BOX ASSEMBLY,	
(SEE FIGURE 7-18)	
CONTROL CHASIS	
ASSEMBLY, LAUNDRY,	
(SEE FIGURE 7-19)	
HOSE, LOW PRESSURE	
ADAPTER, STRAIGHT	
SLEEVE	

FIRE EXTINGUISHER	
PLATE, MOUNTING	
STAND, CONTROLLER SUPPORT	
LOAD CENTER	
ENCLOSURE	
BRACKET, INTERIOR MOUNT	
KIT, INTERIOR TRIM	
CAP, END SEAL	
MAIN BREAKER, 30 AMP	
CIRCUIT BREAKER, 20 AMP	
BOX, 3 GANG	
GASKET, SYNTH-RBR,	
CONNECTOR, RECEPTACLE	
OUTLET	
COVER, CONDUIT	
COVER, LIFT	
SWITCH, MOTOR STARTING	
HEAD ASSEMBLY	
WINDOW, OBSERVATION,	
LATCH, SPECIAL	
LAMP, 28V	-
SOCKET, LAMP NAME PLATE	
WARNING	
NAME PLATE,	
TUBING,	
TYRAP,	
BRACKET, RECEPTACLE	
RECEPTACLE	
ANGLE, CENTER	
DOOR ASSEMBLY, PLASTIC	
WET PART, LAUNDRY	
PARTITION, SWITCH	
SKIRT, TIMING,LAUNDRY	
REAR ASSEMBLY	
BACK	
POWER SUPPLY	
VALVE, SOLENOID,	
STRAINER, SEDIMENT,	
NIPPLE, PIPE,	
ANGLE	·
PLUG, PIPE	
BLOCK, MANIFOLD,	
CONTROL CHASIS ASSEMBLY	
CONTROL PANEL ASSEMBLY,	
(SEE FIGURE 7-20)	
FUSE, CARTRIDGE,	
FUSEHOLDER,	
VALVE, SOLENOID,	
VALVE, AIR CONTROL, 3 WAY	

31 JANUARY 2000 LIST OF DEFECTIVE PARTS AND ASSEMBLIES

COMPONENTS:	REMARKS:
RELAY, 3PDT, IO AMP	
SWITCH, PRESSURE	
RELAY,	
TIMING MOVEMENT,	
MECHANICAL,	
(SEE FIGURE 7-21)	
CONTROL PANEL ASSEMBLY	
PANEL,CONTROL	
TIMER, SEQUENTIAL	
SWITCH, TOGGLE,	
COVER, SWITCH	
REVERSING TIMER ASSEMBLY	
SHAFT, SHOULDERED,	
SWITCH, SENSITIVE,	
ADAPTER, SWITCH	
CAM, CONTROL	
SETSCREW,	
BRACKET, TIMER	
LAUNDRY EXTRACTOR	
ASSEMBLY	
EXTRACTOR, BOCK MOISTRITE	
AND SPEEDRY	
MOTOR ASSEMBLY,	
(SEE FIGURE 7-26)	
MOTOR ASSEMBLY,	
(SEE FIGURE 7-27)	
SHEAVE, PULLEY	
V-BELT	
LID	
FRAME, LID HINCE	
BASKET BALL	
LID GASKET	
CURB ASSEMBLY	
WASHER, LEAD	
RUBBER WASHER	
HOSE,	
BASKET ASSEMBLY	
POST,CENTER	
SEAL,	
CENTER UNIT ASSEMBLY,	
(SEE FIGURE 7-28)	
HUB, BRAKE	
BACK PANEL ASSEMBLY,	
(SEE FIGURE 7,29)	
BASE ASSEMBLY	
TRUNNION FRAME, ASSEMBLY	
COUPLING HALF,	
MOTOR ASSEMBLY #1	
MOTOR, 3 HP	
SWITCH,	

31 JANUARY 2000

LIST OF DEFECTIVE PARTS AN
ASSEMBLIES
REMARKS:

COMPONENTS:	REMARKS:
MOUNT, SWITCH	
COUPLING	
HUB, BODY,	
PLATE, MOTOR MOUNT	
MOTOR ASSEMBLY #2	
MOTOR	
HUB, PULLEY	
PLATE, MOTOR MOUNT	
CENTER UNIT ASSEMBLY	
PIN, STUD	
ARM,BRAKE	
ARM, OPERATING	
BRACKET	
SPRING, HELICAL, EXTENSION	
BRAKE SHOE,	
COVER, TOP END	
SHIELD, SOLENOID	
ROD, SOLENOID	
SOLENOID, BRAKE	
HUB	
BALL,BASKET	
INSERT, NYLON	
PACKING,	
CAP, BUMPER	
BUMPER RUBBERS	
CAP, TRUNNION	
RUBBER, TRUNNION	
HUB, PULLEY	
SHEAVES, PULLEY	
BACK PANEL ASSEMBLY	
BUTTON, START	
SWITCH, PUSH-PULL,	
BUTTON, RED LIGHT, INDICATOR	
MICROSWITCH	
SOLENOID, RELAY,ELECTRO MAGNETIC	
TIMER,	
FUSE HOLDER	
FUSE, CARTRIDGE,	
TERMINAL BOARD	
COVER	
PLATE, BOTTOM	
BACK AND SIDES, CONTROL	
PANEL	
PLATE, MOUNT	
PLATE, MOONT PLATE, TOP	
TIE DOWN CLIP ASSEMBLY	
BAR, TIE DOWN CLIP	
LEG, TIE DOWN CLIP	
DEC, THE DO WITH CLIH	

PLATFORMS WATER PUMP ASSEMBLY WATER PUMP ASSEMBLY FRAME, AL-ALY SWITCH BOX ASSEMBLY COVER, BOX, FRONT PUMP UNIT BRACKET MOTOR, ALTERNATING CAP, COUPLING HALF, NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY DRYER ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY DRYER ASSEMBLY ORY BLOWER ASSEMBLY ORY BLOW
WATER PUMP ASSEMBLY FRAME, AL-ALY SWITCH BOX ASSEMBLY COVERS COVER,BOX,FRONT PUMP UNIT BRACKET MOTOR, ALTERNATING CAP, COUPLING HALF, NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSE, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, FIXED ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY SEE FIGURE 7-35) HOSE ASSEMBLS BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
FRAME, AL-ALY SWITCH BOX ASSEMBLY COVERS COVER, BOX, FRONT PUMP UNIT BRACKET MOTOR, ALTERNATING CAP, COUPLING HALF, NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLAITORM ASSEMBLY BLOWER ASSEMBLY BLOWER ASSEMBLY SEE FIGURE 7-35) HOSE ASSEMBLY (SEE FIGURE 7-356) SWITCHES, SENSITIVE
SWITCH BOX ASSEMBLY COVERS COVER, BOX, FRONT PUMP UNIT BRACKET MOTOR, ALTERNATING CAP, COUPLING HALF, NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRANER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY OUTLING ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, SEE FIGURE 7-35) HOSE ASSEMBLY (SEE FIGURE 7-35) HOSE ASSEMBLES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
COVERS COVER,BOX,FRONT PUMP UNIT PUMP UNIT BRACKET MOTOR, ALTERNATING CAP, COUPLING HALF, NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY BLOWER ASSEMBLY BLOWER ASSEMBLY SEE FIGURE 7-35) HOSE ASSEMBLES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
COVER,BOX,FRONT PUMP UNIT BRACKET MOTOR, ALTERNATING CAP, COUPLING HALF, NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY DRYER ASSEMBLY USEE FIGURE 7-35) HOSE ASSEMBLES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-366) SWITCHES, SENSITIVE
PUMP UNIT BRACKET MOTOR, ALTERNATING CAP, COUPLING HALF, NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY (SEE FIGURE 7-35) HOSE ASSEMBLES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
BRACKET MOTOR, ALTERNATING CAP, COUPLING HALF, NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
MOTOR, ALTERNATING CAP, COUPLING HALF, NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
CAP, COUPLING HALF, NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
COUPLING HALF, NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
NIPPLE, PIPE HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
HOSE CONNECTION ASSEMBLY SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
SUCTION STRAINER ASSEMBLY COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY, (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
COUPLING, QUICK DISCONNECT SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
SUCTION HOSE ASSEMBLY COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
COUPLING, HALF HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
HEATER INTAKE HOSE ASSEMBLY WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY BLOWER ASSEMBLY, (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
WASHER, INTAKE HOSE ASSEMBLY HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
HOSES, WATER, CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
CLOTHES BIN DISCHARGE HOSE EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
EXTRACTOR DISCHARGE HOSE ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY, (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
ASSEMBLY PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY, (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
PUMP TIE DOWN ASSEMBLY CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY, (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
CATCH, FIXED ASSEMBLY CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY, (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
CATCH, ADJUSTABLE PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY, (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
PLATFORM ASSEMBLY DRYER ASSEMBLY BLOWER ASSEMBLY, (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
DRYER ASSEMBLY BLOWER ASSEMBLY, (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
BLOWER ASSEMBLY, (SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
(SEE FIGURE 7-35) HOSE ASSEMBLIES BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
HOSE ASSEMBLIÉS BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36) SWITCHES, SENSITIVE
(SEE FIGURE 7-36) SWITCHES, SENSITIVE
SWITCHES, SENSÍTIVE
COVER
LIGHT, INDICATOR,
ALARM,BUZZER
BUZZER,
DOOR ASSEMBLY
CHAIN, WELDLESS
TIMER, SEQUENTIAL
PLATE, INDENT
LABEL, CAUTION
LABEL, WARNING
ARROW
HANDLE, DOOR
IMIDDE, DOOK
RING ASSEMBLY
·

LIST OF DEFECTIVE PARTS AND ASSEMBLIES

COMPONENTS: REMARKS:

HEATER TUMBLER ASSEMBLY,	
(SEE FIGURE 7-40)	
HOSE, AIR DUCT,	
HOSE, FLEX	
EXHAUST HOSE ADAPTER	
ASSEMBLY	
DUCT, HOSE,	
REDUCER, PIPE,	
ELBOW, AIR CONDITIONING	
HEATING	
PIN ASSEMBLY	
PIN	
CHAIN, SAFETY	
HOOK, CHAIN,	
THERMOMETER	
DISCHARGE SPOUT ASSEMBLY	
COUPLING, HALF	
CONTROL, TEMPERA TURE, DIAL	
AND KNOB	
CONNECTOR, ELBOW,	
BOX CONNECTOR,	
FAN ASSEMBLY, (SEE FIGURE 7-41)	
COVER	
CONTROL PANEL ASSEM BLY,	
(SEE FIGURE 7-42)	
TUMBLER SPEED REDUCER	
ASSEMBLY,	
(SEE FIGURE 7-43)	
ROD, THREADED	
CUP, GREASE,	
CUP OIL,	
PLATES, RETAINING,	
GUARD	
CHAIN, STL, 65 LINKS	
WIRE, SAFETY	
TUMBLER ASSEMBLY,	
(SEE, FIGURE 7-44)	
SHELL ASSEMBLY	
TUMBLER BASE ASSEMBLY	
PANEL, SIDE	
INSULATOR,PLATE,	
STRIP	
BLOWER ASSEMBLY	
GUAGE, PRESSURE	
COCK, DRAIN	
TEE	
NIPPLE	
PUMP, FUEL	
SHUTTER ASSEMBLY,	
HOUSING	
110 00110	

31 JANUARY 2000

LIST OF DEFECTIVE PARTS AND ASSEMBLIES

COMPONENTS:	REMARKS:
HOUSING, BLOWER	
WHEEL, BLOWER	
MOUNT, BLOWER	
KEY	
MOTOR, ALTERNATING	
BURNER TUMBLER ASSEMBLY	
CAP FITTING	
GASKET, PEEP SIGHT,	
GLASS, PEEP HOLE	
NIPPLE	
COVER	
CABLE AND TERMINAL	
ASSEMBLY,	
(SEE FIGURE 7-37)	
ELECTRODE ASSEMBLY,	
(SEE FIGURE 7-38)	
BRACKET, TRANSFORMER	
TRANSFORMER	
BOX, JUNCTION	
COVER	
BOX CONNECTORS,	
CONNECTOR, STRAIGHT	
AIR PLENUM	
CABLE AND TERMINAL	
ASSEMBLY CABLE	
TERMINAL, LUG,	
ELECTRODE ASSEMBLY	
ELECTRODE ASSEMBLT ELECTRODE	
NOZZLE ASSEMBLY	
NOZZLE	
PIPE	
BASE, BURNER	
FRONT SHELL ASSEMBLY	
DOOR	
HINGE ASSEMBLY	
HINGE	
PIN, SPRING	
FRONT, SHELL	
HEATER TUMBLER ASSEMBLY	
SCREEN ASSEMBLY,	
PANEL, COVER	
HOOD ASSEMBLY	
HOOD	
PLATE	
COVER, FRONT	
COVER, REAR	
BURNER MOUNTING ASSEMBLY	
RETURN BOX NO 5 ASSEMBLY	
COVER, ASSEMBLY	

LIST OF DEFECTIVE PARTS AND ASSEMBLIES

COMPONENTS:	REMARKS:
RETURN BOX NO 3 ASSEMBLY	
RETURN BOX NO 1 ASSEMBLY	
RETURN BOX NO 4 ASSEMBLY	
RETURN BOX NO 2 ASSEMBLY	
MOUNTING PLATE ASSEMBLY	
FAN ASSEMBLY	
FAN	
MOTOR, ALTERNATING,	
ARROW	
COVER, WELDMENT	
CONTROL PANEL ASSEMBLY	
STARTER, MANUAL	
PANEL ASSEMBLY	
CONTROL, FLAME	
PROGRAM TIME CARD,	
TERMINAL BOX, 12 SGL	
RELAY	
BASE, RELAY,	
SHIELD ASSEMBLY	
MOTOR, STARTER	
HEATER ELEMENT,	
TUMBLER SPEED REDUCER	
ASSEMBLY	
MOTOR, ALTERNATING	
MOUNTING BRACKET ASSEMBLY	
BASE ASSEMBLY	
TUMBLER ASSEMBLY	
TIE ROD	
RIB, TUMBLER,	
SPIDER ASSEMBLY	
TUMBLER, CLOTHES DRYER	
EXHAUST TIE DOWN	
ASSEMBLY#1	
LEG	
STRAP, WEBBING,	
LOOP THREAD	
EXHAUST TIE DOWN	
ASSEMBLY#2	
LEG	
STRAP	
LOOP	
THREAD	
CONDUIT ASSEMBLY	
GROUND ROD, SECTION	
CONNECTOR, GROUND ROD	
WIRE, #8 STRANDED	
CONDUIT OUTLET	
COVER	
COVER, BLANK	
BODY, CONNECTOR	

LIST OF DEFECTIVE PARTS AND **31 JANUARY 2000**

151	OF	DEFEC	TIVE		KIS	ANI
		ASSEN	ABLI	ES		

COMPONENTS:	REMARKS:
COVER,CONNECTER	
PLUG, NYLON	
PLUG, COVER	
CONNECTOR	
BOX, TWO GANG	
BOX CONNECTOR,	
CLOTHES BIN ASSEMBLY	
HANDLE, SHORT	
HANDLE, LONG	
SIDE	
BASE	
COUPLING	
STAND, CLOTHES BIN	
CASTOR	
PLATFORM	
POWER CABLE ASSEMBLY	
BODY	
SHIELD, ELECTRICAL	
CABLE	

COMPONENTS: REMARKS:

LAUNDRY FACILITY BARE BASE	
MAIN PLATFORM ASSEMBLY,	
(SEE FIGURE 7 2)	
STORAGE BIN ASSEMBLY,	
(SEE FIGURE 7 3)	
LAUNDRY WASHER ASSEMBLY,	
(SEE FIGURE 7-4)	
LAUNDRY WASHER ASSEMBLY,	
(SEE FIGURE 7 7)	
CLAMP ASSEMBLY,	
(SEE FIGURE 7-13)	
COUPLING	
COUPLING HALF,	
QUICK DISCONNECT,	
CAM-LOCKINC ALL ENDS	
PLUG, SQ HD,	
ELBOW, ST BRASS	
BUSHING, BRASS,	
COMPRESSOR UNIT,	
RECIPROCATING,	
(SEE FIGURE 7-14)	
CONTROLLER AND	
ELECTRICAL PANEL,	
(SEE FIGURE 7-16)	
WATER HEATER,	
(SEE FIGURE 7-22)	
HEATER FUEL LINE ASSEMBLY,	
(SEE FIGURE 7-23)	
HEATER TIEDOWN ASSEMBLY,	
(SEE FIGURE 7-24)	
LAUNDRY EXTRACTOR,	
(SEE FIGURE 7-25)	
TIE DOWN CLIP ASSEMBLY,	
(SEE FIGURE 7-30)	
WATER PUMP ASSEMBLY,	
(SEE FIGURE 7-3 1)	
HOSE CONNECT ASSEMBLY,	
(SEE FIGURE 7 32)	
PUMP TIEDOWN ASSEMBLY,	
(SEE FIGURE 7 33)	
DRYER ASSEMBLY,	
(SEE FIGURE 7-34)	
DRYER FUEL LINE ASSEMBLY,	
(SEE FIGURE 7-23)	
EXHAUST HOSE	-
TIEDOWN ASSEMBLY,	
(SEE FIGURE 7-45)	
EXHAUST HOSE	· -
TIEDOWN ASSEMBLY,	

COMPONENTS:	REMARKS:

(SEE, FIGURE 7-46)	
CONDUIT ASSEMBLY,	
(SEE FIGURE 7-47)	
RAIL, SIDE, 84 IN LG	
CLOTHES BIN ASSEMBLY,	
· · · · · · · · · · · · · · · · · · ·	
(SEE, FIGURE 7-49)	
POWER CABLEASSEMBLY,	
(SEE FIGURE, 7 49)	
SPACER	
COVER ASSEMBLY RED 1, 2, & 3	
MAIN PLATFORM ASSEMBLY	
PLATFORM, LEFT ASSEMBLY	
PLATFORM, FRAME ASSEMBLY	
DECK, LARGE TOP ASSEMBLY	
DECK, SMALL TOP ASSEMBLY	
DECK, LARGE BOTTOM ASSEMBLY	
DECK, SMALL BOTTOM ASSEMBLY	
RAIL	
RAIL, SIDE	
SLEEVE	
STRAP, RETAINING,	
PLATFORM, RIGHT ASSEMBLY	
JOINING PANEL ASSEMBLY	
STORAGE BIN ASSEMBLY	
BIN, LARGE	
PLATFORM	
BIN, SMALL	
COVER ASSEMBLY	
FASTENER, LINK LOCK	
TRAY	
LAUNDRY WASHER	
WASHER ASSEMBLY,	
(SEE FIGURE 7-5)	
PLATE, TANK MOUNTING	
ELBOW, PIPE,	
TEE, PIPE, STL,	
COCK, DRAIN,	
WASHER ASSEMBLY, OPEN END	
COVER, BASE SIDE LEFT	
COVER, BASE FRONT	
COVER, BASE SIDE RIGHT	
SUPPLY INJECTOR ASSEMBLY	
SHELL ASSEMBLY	
SHELL FRONT ASSEMBLY	
SHELL, EXTRUSION	
RING, SHELL	
PLATE, MOUNTING	
MICROSWITCH	
CAM, CONTROL	
OI HVI, COIVIICOL	

COMPONENTS:	REMARKS:	

HANDLE ASSEMBLY	
DOOR, ASSEMBLY	
BRACKET, HINGE	
CYLINDER ASSEMBLY	
HOUSING, SHAFT SEAL	
GASKET, SHAFTSEAL	
SEAL, PLAIN, STL,	
COVER, SHAFT RETAINER	
SPACER, SHAFT RETAINER	
KEY, MACHINE, STL	
SPIDER.	
GEAR ASSEMBLY,	
SPEED DECREASER	
MOTOR, ALTERNATING	
MOUNT, MOTOR	
BRACKET, MOTOR MOUNT, LEFT	
BRACKET, MOTOR MOUNT, RIGHT	
BELT GUARD ASSEMBLY	
BRACKET, BELT UPPER	
BELT, V, RBR,	
BRACKET, BELT, LOWER LEFT	
PULLEY, GROOVE,	
BUSHING, SLEEVE	
V-PULLEY	
BUSHING, SLEEVE	
COVER, SYPHON	
BREAKER	
PIPE, ELBOW	
WATER LEVEL FLOAT,	
CHAMBER ASSEMBLY,	
(SEE FIC3URE 7-6)	
SOAP CHUTE	
COVER, SOAP CHUTE	
HINGE, SOAP CHUTE	
ROD, SOAP CHUTE	
PIPE, METALLIC	
HOSE, NONMETALLIC,	
PIPE, WATER INLET	
VALVE, ANGLE,	
WATER LEVEL FLOAT	
CHAMBER ASSEMBLY	
SWITCH, LIQUID LEVEL	
TUBING, GLASS,	
CLAMP, LOOP	
BRACKET, LEVEL CONTROL BRACKET, TOP FLOAT	
CHAMBER	
BRACKET, BOTTOM	
FLOAT CHAMBER	

COMPONENTS:	REMARKS:

FLOAT ASSEMBLY,	
LIQUID LEVEL	
FLOAT	
ROD, FLOAT,	
SPEED NUT	
LAUNDRY WASHER ASSEMBLY	
FRAME ASSEMBLY	
DOOR ASSEMBLY, (SEE FIGURE 7-	
8)	
DOOR LOCK ASSEMBLY,	
(SEE FIGURE 7-9)	
DRAW BAND, WASHER	
EXTRACTOR	
GASKET, RBR CHLOROPRENE	
DRUM FRONT	
CYLINDER ASSEMBLY	
SPIDER AND SHAFT ASSEMBLY	
ROD, THREADED END	
RING, GASKET CLAMP	
GASKET, SOCK	
MOTOR	
PLATE, MOTOR MOUNTING	
ROD, MOTOR ADJUSTING	
BELT	
PULLFY, GROOVE,	
BUSHING, SHEAVE	
DRUM ASSEMBLY	
WATER INLET ASSEMBLY,	
(SEE FIGURE 7-10)	
SHEAVE	
BUSHING, SHEAVE	
GEAR ASSEMBLY,	
PLATE, MOUNTING	
SEAL AND CARRIAGE ASSEMBLY,	
SEAL, PLAIN	
DISPENSER ASSEMBLY,	
(SEE FIGURE 7-11)	
GAUGE, TEMPERATURE	
•	
BOTTLE, SUPPLY	
VALVE ASSEMBLY, DRAIN,	
(SEE FIGURE 7-12)	
PLUG, PIPE	
HOSE, DRAIN	
DOOR ASSEMBLY	
DOOR HINGE AND	
HANDLE	
BASE, DOOR HINGE	
BUSHING, FLANGE,	
PIN, DOOR HINGE	

BEARING, WASHER,	
BAR, DOOR	
FASTENER, PAWL	
BOLT, PIVOT	
BUSHING, SLEEVE	
RING, RETAINING	
WINDOW, OBSERVATION, GLASS,	
GASKET, DOOR GLASS	
FRAME, DOOR	
DRAW BAND, DOOR	
GASKET, DRAW BAND	
GASKET, DOOR	
DOOR LOCK ASSEMBLY	
DOOR LOCK COVER AND SWITCH	
COVER, DOOR LOCK	
SWITCH, PUSH	
BOOT, DUST AND MOISTURE SEAL	
BRACKET, MOUNTING	
BUSHING, ELECTRICAL	
CONDUCTOR,	
SOLENOID,	
SWITCH,	
PLATE, DOOR LOCK	
SPRING, DOOR LOCK	
BAR, DOOR LOCK	
SPRING, DOOR LATCH	
WATER INLET ASSEMBLY	
LEVER, MANUAL CONTROL	
CLEVIS, ROD END,	
CYLINDER ASSEMBLY,	
ROD, ADJUSTINC STUD	
BRACKET, MOUNTING	
COUPLER, FEMALE	
COUPLING HALF,QUICK	
DISCONNECT,	
ELBOW, PIPE,	
NIPPLE, PIPE,	
PIPE, METALLIC,	
ELBOW, PIPE TO HOSE,	
ELBOW, PIPE,	
BUSHING, PIPE	
TEE, PIPE	
VALVE, BALL,	
NIPPLE, PIPE,	
DISPENSER ASSEMBLY	
DISPENSER	
COVER	
HOSE, SUPPLY1	
SUPPLY HOSE, AIR	

COMPONENTS:	REMARKS:
HOSE, SUPPLY 2	
HOSE, SUPPLY 3	
HOSE, SUPPLY 4	
FITTING, HOSE	
COUPLING, PIPE,	
HOSE, SUPPLY INLET	
ADAPTER, STRAIGHT	
VALVE, SOLENOID,	
MANIFOLD, SUPPLY	
BRACKET, MANIFOLD	
MOUNTING	
DRAIN VALVE ASSEMBLY	
PLATE, TOP	
BELLOWS, RUBBER,	
ADAPTER, STRAIGHT,	
PLATE, MOUNTING	
BRACKET	
HOSE, NONMETALLIC,	
PINCH TUBE	
CLAMP ASSEMBLY	
ANGLE	
ROD, THREADED, SHORT	
RING, HANGER	
AIR COMPRESSOR ASSEMBLY	
GRILLE, METAL	
HANDLE, DOOR, L STYLE	
KIT, SWITCH, (SEE FIGURE 7-15)	
HOUSING, AIR COMPRESSOR	
CYLINDER, HEAD ASSEMBLY,	
RIGHT HAND	
CYLINDER HEAD ASSEMBLY,	
LEFT HAND	
MOTOR, ALTERNATING	
CABLE ASSEMBLY,	
PRESSURE SWITCH ASSEMBLY	
SWITCH, PRESSURE	
PLUG, BUTTON	
WIRE ASSEMBLY, BLK	
WIRE ASSEMBLY, WHT	
CONTROLLER AND ELECTRICAL	
PANELSUPPORT FRAME	
ASSEMBLY	
FACE PLATE, LAUNDRY,	
COVER, CONTROLLER	
CONTROLLER ASSEMBLY	
HEAD ASSEMBLY,	
CONTROL BOX, (SEE FIGURE 7-17)	
CONTROL BOX ASSEMBLY,	
(SEE FIGURE 7-18)	

BLOCK, MANIFOLD,

COMPONENTS:	REPAIRS REMARKS:
CONTROL CHASIS	
ASSEMBLY, LAUNDRY,	
(SEE FIGURE 7-19)	
HOSE, LOW PRESSURE	
ADAPTER, STRAIGHT	
SLEEVE	
FIRE EXTINGUISHER	
PLATE, MOUNTING	
STAND, CONTROLLER SUPPORT	
LOAD CENTER	
ENCLOSURE	
BRACKET, INTERIOR MOUNT	
KIT, INTERIOR TRIM	
CAP, END SEAL	
MAIN BREAKER, 30 AMP	
CIRCUIT BREAKER, 20 AMP	
BOX, 3 GANG	
GASKET, SYNTH-RBR,	
CONNECTOR, RECEPTACLE	
OUTLET	
COVER, CONDUIT	
COVER, LIFT	
SWITCH, MOTOR STARTING	
HEAD ASSEMBLY	
WINDOW, OBSERVATION,	
LATCH, SPECIAL	
LAMP, 28V	
SOCKET, LAMP	
NAME PLATE	
WARNING	
NAME PLATE,	
TUBING,	
TYRAP,	
BRACKET, RECEPTACLE	
RECEPTACLE	
ANGLE, CENTER	
DOOR ASSEMBLY, PLASTIC	
WET PART, LAUNDRY	
PARTITION, SWITCH	
SKIRT, TIMING,LAUNDRY	
REAR ASSEMBLY	
BACK	
POWER SUPPLY	
VALVE, SOLENOID,	
STRAINER, SEDIMENT,	
NIPPLE, PIPE,	
ANGLE	
PLUG, PIPE	

COMPONENTS: REMARKS:

CONTROL CHASIS ASSEMBLY	
CONTROL PANEL ASSEMBLY,	
(SEE FIGURE 7-20)	
FUSE, CARTRIDGE,	
FUSEHOLDER,	
VALVE, SOLENOID,	
VALVE, AIR CONTROL, 3 WAY	
RELAY, 3PDT, IO AMP	
SWITCH, PRESSURE	
RELAY,	
TIMING MOVEMENT,	
MECHANICAL,	
(SEE FIGURE 7-21)	
CONTROL PANEL ASSEMBLY	
PANEL,CONTROL	
TIMER, SEQUENTIAL	
SWITCH, TOGGLE,	
COVER, SWITCH	
REVERSING TIMER ASSEMBLY	
SHAFT, SHOULDERED,	
SWITCH, SENSITIVE,	
ADAPTER, SWITCH	
CAM, CONTROL	
SETSCREW,	
BRACKET, TIMER	
LAUNDRY EXTRACTOR	
ASSEMBLY	
EXTRACTOR, BOCK MOISTRITE	
AND SPEEDRY	
MOTOR ASSEMBLY,	
(SEE FIGURE 7-26)	
MOTOR ASSEMBLY,	
(SEE FIGURE 7-27)	
SHEAVE, PULLEY	
V-BELT	
LID	
FRAME, LID HINCE	
BASKET BALL	
LID GASKET	
CURB ASSEMBLY	
WASHER, LEAD	
RUBBER WASHER	
HOSE,	
BASKET ASSEMBLY	
POST,CENTER	
SEAL,	
CENTER UNIT ASSEMBLY,	
(SEE FIGURE 7-28)	
HUB, BRAKE	

TERMINAL BOARD

COMPONENTS:	REMARKS:	
BACK PANEL ASSEMBLY,		
(SEE FIGURE 7,29)		_
BASE ASSEMBLY		_
TRUNNION FRAME, ASSEMBLY		_
COUPLING HALF,		_
MOTOR ASSEMBLY #1		_
MOTOR, 3 HP		_
SWITCH,		_
MOUNT, SWITCH		
COUPLING		_
HUB, BODY,		_
PLATE, MOTOR MOUNT		_
MOTOR ASSEMBLY #2		_
MOTOR		_
HUB, PULLEY		_
PLATE, MOTOR MOUNT		_
CENTER UNIT ASSEMBLY		_
PIN, STUD		_
ARM,BRAKE		_
ARM, OPERATING		
BRACKET		
SPRING, HELICAL, EXTENSION		
BRAKE SHOE,		
COVER, TOP END		
SHIELD, SOLENOID		
ROD, SOLENOID		
SOLENOID, BRAKE		
HUB		
BALL,BASKET		
INSERT, NYLON		
PACKING,		
CAP, BUMPER		
BUMPER RUBBERS		
CAP, TRUNNION		
RUBBER, TRUNNION		
HUB, PULLEY		
SHEAVES, PULLEY		
BACK PANEL ASSEMBLY		
BUTTON, START		
SWITCH, PUSH-PULL,		
BUTTON, RED		
LIGHT, INDICATOR		
MICROSWITCH		
SOLENOID,		
RELAY,ELECTRO MAGNETIC		
TIMER,		
FUSE HOLDER		
FIRE CARTRIDGE		

COMPONENTS:	REMARKS:

COVER	
PLATE, BOTTOM	
BACK AND SIDES, CONTROL	
PANEL	
PLATE, MOUNT	
PLATE,TOP	
TIE DOWN CLIP ASSEMBLY	
BAR, TIE DOWN CLIP	
LEG, TIE DOWN CLIP	
PLATFORMS	
WATER PUMP ASSEMBLY	
WATER PUMP ASSEMBLY	
FRAME, AL-ALY	
SWITCH BOX ASSEMBLY	
COVERS	
COVER,BOX,FRONT	
PUMP UNIT	
BRACKET	
MOTOR, ALTERNATING	
CAP, COUPLING HALF,	
NIPPLE, PIPE	
HOSE CONNECTION ASSEMBLY	
SUCTION STRAINER ASSEMBLY	
COUPLING, QUICK DISCONNECT	
SUCTION HOSE ASSEMBLY	
COUPLING, HALF	
HEATER INTAKE HOSE ASSEMBLY	
WASHER, INTAKE HOSE ASSEMBLY	
HOSES, WATER,	
CLOTHES BIN DISCHARGE HOSE	
EXTRACTOR DISCHARGE HOSE	
ASSEMBLY	
PUMP TIE DOWN ASSEMBLY	
CATCH, FIXED ASSEMBLY	
CATCH, ADJUSTABLE	
PLATFORM ASSEMBLY	
DRYER ASSEMBLY	
BLOWER ASSEMBLY,	
(SEE FIGURE 7-35)	
HOSE ASSEMBLIES	
BURNER TUMBLER ASSEMBLY,	
(SEE FIGURE 7-36) SWITCHES, SENSITIVE	
COVER	
LIGHT, INDICATOR,	
ALARM,BUZZER	
BUZZER,	
DOOR ASSEMBLY	
DOOL INDITATION I	

COMPONENTS:	REMARKS:

CHAIN, WELDLESS	
TIMER, SEQUENTIAL	
PLATE, INDENT	
LABEL, CAUTION	
LABEL, WARNING	
ARROW	
HANDLE, DOOR	
RING ASSEMBLY	
FRONT SHELL ASSEMBLY,	
(SEE FIGURE 7-39)	
HEATER TUMBLER ASSEMBLY,	
(SEE FIGURE 7-40)	
HOSE, AIR DUCT,	
HOSE, FLEX	
EXHAUST HOSE ADAPTER	-
ASSEMBLY	
DUCT, HOSE,	
REDUCER, PIPE,	
ELBOW, AIR CONDITIONING	
HEATING	
PIN ASSEMBLY	
PIN	
CHAIN, SAFETY	
HOOK, CHAIN,	
THERMOMETER	
DISCHARGE SPOUT ASSEMBLY	
COUPLING, HALF	
CONTROL, TEMPERA TURE, DIAL	
AND KNOB	-
CONNECTOR, ELBOW,	
BOX CONNECTOR,	
FAN ASSEMBLY, (SEE FIGURE 7-41)	
COVER	
CONTROL PANEL ASSEMBLY,	
(SEE FIGURE 7-42)	
TUMBLER SPEED REDUCER	
ASSEMBLY,	
(SEE FIGURE 7-43)	
ROD, THREADED	
CUP, GREASE,	
CUP OIL,	
PLATES, RETAINING,	
GUARD	
CHAIN, STL, 65 LINKS	
WIRE, SAFETY	
TUMBLER ASSEMBLY,	
•	
(SEE, FIGURE 7-44)	
SHELL ASSEMBLY	
TUMBLER BASE ASSEMBLY	

PIN, SPRING

REPAIRS REMARKS:
KEWI MCKS.

COMPONENTS: REMARKS:

FRONT, SHELL	
HEATER TUMBLER ASSEMBLY	
SCREEN ASSEMBLY,	
PANEL, COVER	
HOOD ASSEMBLY	
HOOD	
PLATE	
COVER, FRONT	
COVER, REAR	
BURNER MOUNTING ASSEMBLY	
RETURN BOX NO 5 ASSEMBLY	
COVER, ASSEMBLY	
RETURN BOX NO 3 ASSEMBLY	
RETURN BOX NO 1 ASSEMBLY	
RETURN BOX NO 4 ASSEMBLY	
RETURN BOX NO 2 ASSEMBLY	
MOUNTING PLATE ASSEMBLY	
FAN ASSEMBLY	
FAN	
MOTOR, ALTERNATING,	
ARROW	
COVER, WELDMENT	
CONTROL PANEL ASSEMBLY	
STARTER, MANUAL	
PANEL ASSEMBLY	
CONTROL, FLAME	
PROGRAM TIME CARD,	
TERMINAL BOX, 12 SGL	
RELAY	
BASE, RELAY,	
SHIELD ASSEMBLY	
MOTOR, STARTER	
HEATER ELEMENT,	
TUMBLER SPEED REDUCER	
ASSEMBLY	
MOTOR, ALTERNATING	
MOUNTING BRACKET ASSEMBLY	
BASE ASSEMBLY	
TUMBLER ASSEMBLY	
TIE ROD	
RIB, TUMBLER,	
SPIDER ASSEMBLY	
TUMBLER, CLOTHES DRYER	
EXHAUST TIE DOWN	
ASSEMBLY#1	
LEG	
STRAP, WEBBING,	
LOOP	
THREAD	

	REP.

COMPONENTS:	REMARKS:
EXHAUST TIE DOWN	
ASSEMBLY#2	
LEG	
STRAP	
LOOP	
THREAD	
CONDUIT ASSEMBLY	
GROUND ROD, SECTION	
CONNECTOR, GROUND ROD	
WIRE, #8 STRANDED	
CONDUIT OUTLET	
COVER	
COVER, BLANK	
BODY, CONNECTOR	
COVER,CONNECTER	
PLUG, NYLON	
PLUG, COVER	
CONNECTOR	
BOX, TWO GANG	
BOX CONNECTOR,	
CLOTHES BIN ASSEMBLY	
HANDLE, SHORT	
HANDLE, LONG	
SIDE	
BASE	
COUPLING	
STAND, CLOTHES BIN	
CASTOR	
PLATFORM	
POWER CABLE ASSEMBLY	
BODY	
SHIELD, ELECTRICAL	
CABLE	

(1 Data Item)

Form Approved OMB No. 1704-0188

17 PRICE GROUP

18. ESTIMATED TOTAL PRICE

The Public reporting burden for this collection of information is authorized to average 110 hours per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302 and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503. Please DO NOT RETURN your form to either of these addresses. Send completed form to the Government issuing Contract Officer for the contract/PR No. listed in block E.

A. CONTRACT LINE ITEM NO. B. EXHIBIT

C. CATEGORY:

	Zimi i Zimi i i			TDP		ΤM	Other XX	XX				
D. SYSTEM/ĪTI	FM -		E. CONTRACT/P		F. CONT		<u> </u>					
	zed Bare Base La	undrv										
_ miles all	Facility											
I. DATA ITEM No. I	2. TITLE OF DATA ITEM		ı		3. SUBTITLE							
A001	Contractor's Pro		tatus, and Mana	gement Report		Monthly Progr	ess Repo	ort				
4 AUTHORITY (Dat	ta Acquisition Document No.	j	5. CONTRACT REFER	ENCE		6. REQUIRING OFFICE	· .					
DI	-MGMT-80227			SOW 4.2		MARCORL	OGBASI	ES (837)				
	9. DIST STATEMENT	10. FREQUE		12. DATE OF FIRST S		14. DIS						
LT	REQUIRED		MTHLY	See Blk 16 13. DATE OF SUBSEQUENT			b. COPIES					
8. APP CODE	A	11. AS OF D	DATE	SUBMISSION See Blk		a. ADDRESSEE	Draft	Reg	Repro			
16. REMARKS		1		Bee Bik	10	MCLBA (837-1)	0	1	0			
Contractor fo	ormat is authorize	ed.										
						-	+	 	1			
	ilor DI-MGMT-8 10.3k, and 10.3n.	0227 as f	follows: Delete p	paragraphs 10.3g	g, 10.3h,		 					
, 3,	,							ļ	 			
	he reporting perio				day of	_	+	† 	1			
each month.	Initial submission	n shall be	e 60 days after co	ontract.		_	<u> </u>	<u> </u>	Ì			
01 1 12 0		. ,	11.1 10.1 0		,							
	ubsequent submis	ssions sha	all be 10 days at	ter the last busin	iess day		<u> </u>					
of each month	п.						 					
Distribution S	Statement A: App	roved for	r nublic release	distribution is u	nlimited		 	1				
Distribution E	statement 7t. 7tpp	10104 10	public release,	distribution is a			+					
						_	· · · · · · ·					
							 	 	 			
						_		 	 			
							T					
							1					
							<u> </u>					
								-	—			
							+	 -	 			
							+	-	 			
							╅	1	-			
						,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	+		 			
							1					
						_		<u> </u>	†			
						-						
							 	ļ	 			
							1					
							+		_			
				r_{\perp}		15. TOTAL		1	0			
G. PREPARED	BY: 🔿 🖊		H. DATE	II. APPKOYEDA	SY;	15. TOTAL	0 J. DAT	l E	0			
G. PREPARED	BY:		H. DATE	I. APPROVEDA	\$y. 	15. TOTAL	J. DAT	1 E	<u> </u>			

(1 Data Item)

Form Approved OMB No. 1704-0188

Designed using Perform Pro, WHS/D/or, Aug 96

17. PRICE GROUP

18. ESTIMATED TOTAL PRICE

The Public reporting burden for this collection of information is authorized to average 110 hours per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302 and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503. Please DO NOT RETURN your form to either of these addresses. Send completed form to the Government issuing Contract Officer for the contract/PR No. listed in block E.

	pieted form to the Governme.										
A. CONTRACT	LINE ITEM NO.	B. EXHII	BIT	C. CATEGORY	:	TM	Other XX	××			
D. SYSTEM/IT	ΈM	1	E. CONTRACT	TDP T/PR No	IF CONT	RACTOR	Other X2	<u></u>			
	zed Bare Base La	undry	L. CONTRACT	/1 IC 110.	I CONT	RECIOR					
Gandardi	Facility	aurur y									
DATA ITEM No.	2. TITLE OF DATA ITEM	1			3. SUBTITE	E					
B001	Repa	irable lte	m Inspection I	Report							
. AUTHORITY (Da	uta Acquisition Document No	0.)	5. CONTRACT REF.	ERENCE		6. REQUIRING OFFICE					
Ι	OI-ILSS-80386			SOW 4.1		MARCOR	LOGBASI	ES (837)			
. DD 250 REQ.	9. DIST STATEMENT	10. FREQUI			12. DATE OF FIRST SUBMISSION		14 DISTRIBUTION				
LT	REQUIRED	1	AS REQ	See Blk 16				b. COPIES			
APP CODE	A	11. AS OF I	DATE	13. DATE OF SUBSE SUBMISSION		a ADDRESSEE	Draft	Reg Fin	NAL Repro		
6. REMARKS	<u> </u>			See Blk	. 10	MCLBA (837-1)	0	1	0		
). REFERENCE						WICLDA (657-1)	-	 	U		
lock 4 - Co	ntractor format is	authoriz	ed.					-			
llock 10 - A	separate report s	hall be su	ibmitted for St	andardized Bare l	Base			├ ──	-		
	ility repaired.	man oc su	omitted for ot	unduranzou Dale I	-400			₩	<u> </u>		
aundry 1 ac	miy repaired.							Ь——	<u> </u>		
lack 12 & 1	13 – Submit repoi	rt hu Mar	ine Corne Seri	al Number 30 das	s after			—	<u> </u>		
nmnlation o	of each Standardiz	red Rore l	Race Launder	ar mamoer oo aay Facility	S HILLI			 	ļ		
ompiciton o	ri Cacii Standardiz	eu Daic i	Dasc Laundry	i actifity.				└			
lask 14 D	amanta ahali ha m	idad h	and asmu					<u> </u>	ļ		
10CK 14 – K	leports shall be pr	iovidea ii	ard copy.					<u> </u>	<u> </u>		
	C4-4	1 C-		والمناسبة المناسبة المناسبة	المحفق سيفاس		_				
istribution a	Statement A: App	proved 10	r public release	e, distribution is t	ımımıea			<u> </u>	ļ		
								<u> </u>			
								<u> </u>			
									ļ		
								<u> </u>			
								<u> </u>	↓		
								↓	<u> </u>		
								<u> </u>	↓		
									<u> </u>		
								<u> </u>	<u> </u>		
								<u> </u>	<u> </u>		
								<u> </u>	<u> </u>		
								<u> </u>	<u> </u>		
									<u> </u>		
					/ /	15. TOTAL	0	l	0		
G. PREPARED) BY		H. DATE	I. APPROVED	B <u>y/ / </u>		J. DAT	Е			
MOL		41	00 -0 -	a 1/1//	1. J		1º L	172	e .		
ON FORM	12 1 AUC 96 (PC)	46	00-02-1	US EDITION MAY BE US	En .			age 1 of			
レレ r UMM 14	40-1, AUG 90 (EG).		FREYIU	COEDITOR MAT BE US			Pa	age I Of	ı rap		

(1 Data Item)

Form Approved OMB No. 1704-0188

The Public reporting burden for this collection of information is authorized to average 110 hours per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302 and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503. Please DO NOT RETURN your form to either of these addresses. Send completed form to the Government issuing Contract Officer for the contract/PR No, listed in block E. C. CATEGORY A. CONTRACT LINE ITEM NO. B. EXHIBIT Other XXX F. CONTRACTOR D. SYSTEM/ITEM E. CONTRACT/PR No. Standardized Bare Base Laundry **Facility** 3. SUBTITLE 2. TITLE OF DATA ITEM Configuration Management Request for Waiver (RFW) C001 CONTRACT REFERENCE 6. REQUIRING OFFICE 4. AUTHORITY (Data Acquisition Document No.) MARCORLOGBASESALB 825 SOW 3.3.2 **DI-CMAN-80641B** 12. DATE OF FIRST SUBMISSION DISTRIBUTION 7, DD 250 REQ. DIST STATEMENT REQUIRED See Blk 16 LT AS REQ 13. DATE OF SUBSEQUENT 8 APP CODE 11. AS OF DATE a. ADDRESSEE SUBMISSION Repro 16. REMARKS MCLBA 825-2 0 0 Block 4: Contractor format using .doc or .pdf software is authorized. Blocks 10 & 12: RFWs shall be submitted to obtain authorization to deliver nonconforming material which does not meet the prescribed configuration documentation. RFWs will be reviewed and disposition determined within 30 calendar days upon receipt by the government. RFWs shall be transmitted via e-mail to the following address: mbmatcomconfigmngmnt@matcom.usmc.mil Distribution Statement A: Approved for public release, distribution is unlimited. 15. TOTAL 0 G. PREPARED BY: J. DATE

17. PRICE GROUP

18. ESTIMATED TOTAL PRICE

Page 1 of 1 Pages Designed using Perform Pro, WHS/D/or, Aug 96

(1 Data Item)

Form Approved OMB No. 1704-0188

Designed using Perform Pro, WHS/D/or, Aug 96

17. PRICE GROUP

18. ESTIMATED TOTAL PRICE

The Public reporting burden for this collection of information is authorized to average 110 hours per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Department of Defense. Washington Headquarters Services, Directorate for Information Operations and Reports 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302 and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503 Please DO NOT RETURN your form to either of these addresses. Send completed form to the Government isguing Contract Officer for the contract/PR No. listed in block E.

A. CONTRACT	I LINE ITEM NO.	B. EXHIB	BIT	C. CATEGORY		TM	Othor VV	/V		
D. SYSTEM/IT	`FM	⊥	E. CONTRACT/PI	TDP R No.		TM RACTOR	Other XX	<u> </u>		
	zed Bare Base La Facility	undry								
. DATA ITEM No.	2. TITLE OF DATA ITEM		- · · / / / / / / / / / / / / / / / / /		3. SUBTITL					
C002		_	Deviation (RFD)		Configuration N	Aanagem	ent 		
. AUTHORITY (De	ua Acquisition Document No.	J	5. CONTRACT REFERE	ENCE	_	6 REQUIRING OFFICE		<u>-</u>		
DI	-CMAN-80640B		5	SOW 3.3.2		MARCORLO	OGBASES	ALB 82	5	
7. DD 250 REQ.	9. DIST STATEMENT REQUIRED	10. FREQUE				14. DISTRIBUTION 6. COPIES				
LT B. APP CODE		11. AS OF D	AS REQ	See Blk 16 13. DATE OF SUBSEQUENT			FINAL			
. APP CODE	A	II. AS OF D	ATE	SUBMISSION	BOOENI	a. ADDRESSEE	Draft	Reg	Repro	
6. REMARKS						MCLBA 825-2	0	T	0	
Blocks 10 & conconformition of the second se	ntractor format using the state of the state	e submitt n does no sposition	ed to obtain auth t meet the prescr	orization to de ibed configura	tion					
	e transmitted via			ldress:			1			
nbmatcomco	onfigmngmnt@m	atcom.usi	mc.mil							
Nietribution '	Statement A: App	roved for	r public release	distribution is a	unlimited					
) isu iou iioii	outement 11. 11pp	70 V Cu 10	public release,	distribution is	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	` 		ļ	 	
							 		 	
							+		 	
							1			
									L	
							_	ļ		
						<u> </u>	-	 _	}	
							 -	<u> </u>	<u> </u>	
							+	 	 	
							+	 	 	
							+	<u> </u>	 	
							+	<u></u>	┼	
							+		 	
							 	 		
							+		 	
							+	 	 	
						15. TOTAL	0	1	0	
G PREPARED	BY:CD	7/	H. DATE	I. APPRÓVED	BY:	-	J. DATI	<u>. </u>		
Winne	L. KAUG	lli	FEB 15 28	10			1,5	13,8		
DD PORM 14	23-1, AUG 96 (EG)	- 7 /	PREVIOUS	EDITION MAY BE U	SED .		Pa	ge 1 of	1 Pag	